

Autonics
Temperature Transmitters
with HART protocol
KT-502H SERIES

INSTRUCTION MANUAL



Thank you for choosing our Autonics product.
Please read the following safety considerations before use.

■ Safety Considerations

- ※Please observe all safety considerations for safe and proper product operation to avoid hazards.
- ※⚠ symbol represents caution due to special circumstances in which hazards may occur.

⚠ Warning Failure to follow these instructions may result in serious injury or death.
⚠ Caution Failure to follow these instructions may result in personal injury or product damage.

⚠ Warning

- Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss.** (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.)
Failure to follow this instruction may result in personal injury, economic loss or fire.
- Do not use the unit in the place where flammable/explosive gas, high humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present.**
Failure to follow this instruction may result in explosion or fire.
- Do not connect, repair, or inspect the unit while connected to a power source.**
Failure to follow this instruction may result in electric shock or malfunction.
- For installing the unit, ground it exclusively and use over AWG 11(4mm²) ground cable.**
Failure to follow this instruction may result in electric shock.
- Do not disassemble or modify the unit.**
Failure to follow this instruction may result in fire or electric shock.
- Check 'Connections' before wiring.**
Failure to follow this instruction may result in fire.

⚠ Caution

- Use the unit within the rated specifications.**
Failure to follow this instruction may result in fire or product damage.
- Use a dry cloth to clean the unit, and do not use water or organic solvent.**
Failure to follow this instruction may result in fire or electric shock.
- Keep the product away from metal chip, dust, and wire residue which flow into the unit.**
Failure to follow this instruction may result in fire or product damage.

■ Ordering Information

KT — 502H 0 (-270 to 1372, K)^{*1}

Item	①		②	
① Mounting bracket	0	Without bracket	1	With bracket
② Input range	※ 1: To order this unit, write the temperature sensor type and the input range.			

■ Input Type and Range

Input type		Input range (°C)	Input range (°F)
RTD	DPT100Ω	-200 to 850	-328 to 1562
	DPT500Ω	-200 to 250	-328 to 482
	DPT1000Ω	-200 to 250	-328 to 482
	Cu50Ω	-50 to 150	-58 to 302
	Cu100Ω	-50 to 150	-58 to 302
	Ni100Ω	-60 to 180	-76 to 356
Resistance transmitter	Ni500Ω	-60 to 180	-76 to 356
	Ni1000Ω	-60 to 150	-76 to 302
	Resistance (Ω)	0 to 400Ω	—
		0 to 2000Ω	—
Thermocouple	B (PtRh30-PtRh6)	0 to 1820	32 to 3308
	E (NiCr-CuNi)	-270 to 1000	-454 to 1832
	J (Fe-CuNi)	-210 to 1200	-346 to 2192
	K (NiCr-Ni)	-270 to 1372	-454 to 2501.6
	N (NiCrSi-NiSi)	-270 to 1300	-454 to 2372
	R (PtRh13-Pt)	-50 to 1768	-58 to 3214.4
	S (PtRh10-Pt)	-50 to 1768	-58 to 3214.4
Analog	T (Cu-CuNi)	-270 to 400	-454 to 752
	Voltage	-10 - 75mV	—
		-100 - 100mV	
		-100 - 500mV	
		-100 - 2000mV	

※ The above specifications are subject to change and some models may be discontinued without notice.
※ Be sure to follow cautions written in the instruction manual and the technical descriptions (catalog, homepage).

■ Specifications

Series		KT-502H
Power supply		10.5-45VDC (with backlight LCD)
Display method		PV display part : 7-segment 5-digit (character size: W4×H8mm), Parameter display part : 14-segment 8-digit (character size: W2.6×H4.8mm), 52-bar meter
Display range		-19999 to 99999
Setting method		HART-protocol (no setting key)
Response time		1 sec
Input type	RTD	DPt100Ω, DPt500Ω, DPt1000Ω Ni100Ω, Ni500Ω, Ni1000Ω Cu50Ω, Cu100Ω
	Thermocouple	K, J, T, E, N, S, B, R
	Resistance trans. (Ω)	0 - 400Ω, 0 - 2000Ω
	Voltage trans. (mV)	- 10 - 75mV - 100 - 100mV - 100 - 500mV - 100 - 2000mV
Output		DC4-20mA (2-wire)
Accuracy		±0.3%
Alarm		Below 3.8mA, Over 20.5mA / Sensor break 3.6mA
Load		max. (V power supply - 7.5V)/0.22A
Galvanic insulation		2kVAC (input/output)
Environ- ment	Ambient temp.	-20 to 70 °C, storage: 20 to 80 °C
	Ambient humi.	0 to 85%RH, storage: 0 to 85%RH
Explosion class※ ¹		Ex d IIC T6
Protection structure		IP67
Material		Body: Aluminum (AlDc.8S), Cover O-Ring: Buna N
Weight※ ²		Approx. 1.4 kg (approx. 1.2 kg)

※1: The explosion class specification is acquired and managed by KONICS.
※2: The weight includes packaging. The weight in parenthesis is for unit only.
※Environment resistance is rated at no freezing or condensation.

■ Error Display and Troubleshooting

Display	Error	Troubleshooting
Err05	Temperature sensor A, B or all sensors are disconnected.	Check the temperature sensor.
Err06	Temperature sensor B is disconnected.	
Err07	When PV is lower than the low-limit value of set temperature range.	Check low-limit value of the set temperature range.
Err08	When PV is higher than the high-limit value of set temperature range.	Check high-limit value of the set temperature range.

■ Temperature Range Setting

Connect a HART communicator and set temperature range as below by a HART communicator.

Online (Generic) 1. Device Setup 2. PV 3. PV Ao 4. PV LRV 5. URV	SAVE
---	------

1. PV LRV 2. URV	HELP HOME
---------------------	-----------

PV LRV 0.000 deg C	HELP DEL ESC ENTER
-----------------------	--------------------

1. PV LRV 2. URV	HELP HOME
---------------------	-----------

PV URV 100.000 deg C 100.000	HELP DEL ESC ENTER
------------------------------------	--------------------

1. PV LRV 0.000 deg C 2. URV 100.000 deg C	HELP SEND HOME
---	----------------

- WARNING - Pressing 'OK' will change device output put 100P in manual	OK
---	----

- WARNING - Return control 100P To automatic control	OK
--	----

1. PV LRV 0.000 deg C 2. URV 100.000 deg C	HELP HOME
---	-----------

- Press the key for 3 sec.
Select the '4. PV LRV' by , keys and press the key.

- Select '1. PV LRV' (Low temperature range) and press the key.

- Set Low temperature range and press the (F4) key.

- Select '2. URV' (High temperature range) and press the key.

- Set High temperature range and press the (F4) key.

- When the set temperature range is correct, press the (F2) key.

- Press the (F4) key.

- Press the (F4) key.

- Check the set temperature range.
Press the (F3) key.
HART communication is OFF.

■ Current Trim Adjustment

Connect a HART communicator and adjust current trim as below by a HART communicator.

1. Device Setup 2. PV 3. PV Ao 4. PV LRV 5. URV

- Select the '1. Device Setup' by , keys and press the key.

1. Process Variables 2. Diag/Service 3. Basic Setup 4. Detailed Setup 5. Review

- Select the '2. Diag/Service' by , keys and press the key.

1. Test device 2. Loop test 3. Calibration 4. D/A trim

- Select the '4. D/A trim' by , keys and press the key.

WARN-Loop should be removed from automatic control	ABORT OK
--	----------

- Press the (F4) key.

Connect reference meter	ABORT OK
-------------------------	----------

- Press the (F4) key.

Setting fid dev output to 4mA	ABORT OK
-------------------------------	----------

- Press the (F4) key.

Enter meter Value 4.000	HELP DEL ABORT ENTER
----------------------------	----------------------

- Press the (F4) key to set 4 mA display value.

Fid dev output 4.000 mA equal to reference meter ? 1. Yes 2. No	ABORT ENTER
---	-------------

- If output display value is correct, select '1. Yes' and press the (F4) key. If not, select '2. No' and press the (F4) key and re-set the display value.
E.g.) If output display value is 3.89mA, select 3.89 and press the (F4) key.

Setting fid dev. output to 20mA	ABORT OK
---------------------------------	----------

- Press the (F4) key.

Enter meter Value 20.000	HELP DEL ABORT ENTER
-----------------------------	----------------------

- Press the (F4) key to set 20mA display value.

Fid dev output 20.000 mA equal to reference meter ? 1. Yes 2. No	ABORT ENTER
--	-------------

- If output display value is correct, select '1. Yes' and press the (F4) key. If not, select '2. No' and press the (F4) key and re-set the display value.

NOTE-Loop may be returned to automatic control	ABORT OK
--	----------

- Press the (F4) key.

Diag/Service 1. Test device 2. Loop test 3. Calibration 4. D/A trim	HELP SAVE HOME
---	----------------

- Press the (F3) key.


Device Disconnected	RETRY QUIT
---------------------	------------

- Press the (F3) key.


1. Offline 2. Online 3. Frequency Device 4. Utility
--

- Press the (F3) key to complete the adjustment.


■ Dimensions



■ Opening Cover



■ Connections



■ Cautions During Use

- Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
 - Power supply should be insulated and limited voltage/current or Class 2, SELV power supply device.
 - Keep away from high voltage lines or power lines to prevent inductive noise. Do not use near the equipment which generates strong magnetic force or high frequency noise.
 - Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power.
 - The explosion-proof standard of this unit is Ex d IIC T6, protection structure of this unit is IP67 and the range of max. surface temperature is below 85 °C. Use the verified explosion-proof electric connection (cable gland or sealing fitting)
 - This unit may be used in the following environments.
 - ① Indoors (in the environment condition rated in 'Specifications')
 - ② Altitude max. 2,000m
 - ③ Pollution degree 2
 - ④ Installation Category II
- ※ The explosion-proof unit is certified and the same specifications which is reported to Korea Gas Safety Corporation. (This unit is manufactured following by the announcement 2013-54 of Ministry of Employment and Labor of Korea.)