

## 고정도 디지털 지시 경보계

## HIGH ACCURACY DIGITAL INDICATOR WITH ALARM

## FEATURES

- ◎ 5 Digit, High Accuracy
- ◎ Multi-range input (T/C, RTD, Volt, mA, Etc)
- ◎ High accuracy 16bit A/D converter
- ◎ Peak hold function (Exit & Hold)
- ◎ RS-485 Communication interface
- ◎ 4 points alarm & Dead band set
- ◎ Isolation current output (DC 4.00~20.00mA) & Output scaling
- ◎ Filter function (4, 8, 16, 32)
- ◎ Auto zero function (Exit)
- ◎ Sensor power source DC 24V in STD specification



## SPECIFICATIONS

- ▷ Measuring and display cycle : 200ms(mV, Volt, mA type)  
400ms(TC, RTD type)
- ▷ Input resistance : Volt-400kΩ  
Others type-1MΩ
- ▷ Signal source resistance : Pt 100Ω type-30Ω/line  
Others type-300Ω/line
- ▷ CMRR(Common Mode Rejection Ratio) : 140dB or more
- ▷ NMRR(Normal Mode Rejection Ratio) : 60dB or more
- ▷ Moving average filter : 4, 8, 16, 32
- ▷ Built-in sensor power source : DC 24V 30mA ±0.5%
- ▷ Accuracy : ±0.15% FS
- ▷ Isolation current output(Option)
  - Current : DC 4.00~20.00mA
  - Maximum load resistance : 600Ω
  - Isolation resistance(Input-Output) : 100MΩ or more  
(DC 500V)
- ▷ Ambient temperature & Humidity
  - Operation : -10~50°C, 10~90%
  - Storage : -20~70°C, 5~95%

## ▷ Alarm(Option)

- Contact output type : Normal open
- Max switching power : 60W 125VA
- Max switching voltage : DC 220V, AC 250V
- Max switching current : DC 2A, AC
- Max Carrying current : DC 3A, AC

## ▷ Power supply

- Voltage : AC 85~265V(45~65Hz)  
DC 24V(Option)
- Power consumption : Max 4VA
- Isolation resistance : 100MΩ , DC 500V  
(FG-Input, FG-Power,  
Power-Input, Input-Output)

## ▷ Communication interface(Option)

- Type : RS-485
- Speed : 4800, 9600, 19200bps
- ID(address) setting : 0~15


## ▷ Etc

- Weight : 500g
- Mounting : Panel mount
- Dimension : 99(W) X 51(H) X 112(D)mm

## 고정도 디지털 지시 경보계

## HIGH ACCURACY DIGITAL INDICATOR WITH ALARM

## PARTS NAME




- ① Measured value display
- ② Alarm condition display
- ③ MODE Key : Storage the set data and change the operation menu
- ④ → Key : Enter into the data setting mode and modify the changed location
- ⑤ ↑ Key : Change the data value
- ⑥ EXIT Key : Out of mode
- ⑦ Hold Function

## ▶ Output scaling function

This function can change the 4.00~20.00mA value as the output scale.

Ex) In case of display value 0.00~7.00m,  
Output 4.00~20.00mA




## ▶ Sensor compensation function

The function is useful for compensating error by long sensor line or changed zero point by aged sensor.

Ex) Before sensor adjust = 510°C

After sensor adjust

$$\begin{aligned} &= \text{measured value} + \text{compensated value} \\ &= 510 - 10 = 500^\circ\text{C} \end{aligned}$$



## ▶ Function(mV, Volt, mA type only)


**L in**

Pass the input as it is.

Used for general input type and linearity input.

**root**

Pass the input after  $\sqrt{\cdot}$ . Used for flow rate by orifice.



**L in&t**

Like level measuring, when it does not display measuring under zero, it always can display zero by using limit function.

## ▶ Filter function

4-Kinds of average transfer filter function.

-AV : Recently, averaging inputting sample value(4,8,16,32) indication.

- \* 1) Because input is irregular use when output and display are unstable.
- 2) When need high speed reply, if use filter, response is slow.


This Function changes and sets the display value according to scale and input range.

## MAJOR FUNCTIONS

## ▶ Display scaling function(mV, Volt, mA only)

This Function changes and sets the display value according to scale and input range.

Ex) In case of input range 4.00~20.00mA and  
Level 0.00~7.00m



▶ Alarm function

Alarm type : High, Low

The alarm consists of 4 relays, and it can output relay contact output individually.


Ex) AL-1 : High alarm value 500.0,

AL-2 : Low alarm value 100.0,

Alarm dead band setting 0.5

The high alarm(AL-1) is ON when the present value(PV) is 500.0 or more, and OFF when 499.5 or less.

The low alarm(AL-2) is OFF when the present value(PV) is 100.5 or more, and ON when 100.0 or less.



▶ Exit Hold function

If dry contact is imposed to external termination present value holding(Transmission output holding).

▶ Auto zero(only mV, V)

▶ If dry contact is imposed to external termination present value Data Zero become.

▶ If establish by Zero in S-AD that is return

▶ Communication interface

It is possible to communicate with computer and to monitor remote by using RS-485 communication.

▶ Peak hold function

**Peak mode 0** High peak mode

Remember the highest input value and display the highest value when pressing the key.

**Peak mode 1** Low peak mode

Remember the lowest input value and display the lowest value when pressing the key.


**Peak mode 2** High peak & Display mode

Remember the highest input value, display the highest value in ordinary times, and output the highest transmit output.

**Peak mode 3** Low peak & Display mode

Remember the lowest input value, display the lowest value in ordinary times, and output the lowest transmit output.

OPERATION MODE



A

B

C

D

E

F

G

H


I

J

## ORDERING CODE

NE 3			-		Description
Type	1				Indicator
	2				Indicator with 2Alarm
	3				Indicator with 4Alarm
Analog output	0				None
	1				DC 4.00~20.00mA
	2				Etc
Power	0				AC 85~265V (45~65Hz)
	1				DC 24V
Interface	0				None
	1				RS-485
	2				Etc

## TERMINAL DIAGRAM



## DIMENSION &amp; PANEL CUT

